

Chapter 26 - Walkways, Driveway, and Parking Pad

Components

Flat Concrete

○

Timing & Prerequisites

- The conductor lines must be installed before the concrete sidewalks. If the conductor lines are not installed in time, the contractor will place pieces of pipe under the walk before they pour them. The ends of the pipe should be marked with a stake.
- All work involving heavy equipment and trucks must be complete before pouring the flat concrete.

The contractor hired by Habitat will form-up the steps, walks, and driveway / parking pad. They will then pour all of the flat concrete.